

ECAM Quick Installation Guide

Thank you for purchasing the Vivitar ECAM Digital Camera. This guide will quickly familiarize you with the basic feature and simple operation of the Vivitar ECAM.

Battery Installation

The ECAM uses a standard 9-volt DC battery. To Install: Attach the leads and place the battery on the right side of the enclosure. Close the cover and installation is complete!

To take a picture

1. Press the power button (located on the right side).
2. While viewing your subject through the view window press the shutter button to capture the image. The camera will signal an audible alert that the image has been captured.

Self timer

The ECAM has a 10 seconds self-timer. To use this function hold the self-timer button down and press the shutter button. This will activate the LED which will begin to flash one second at a time. 10 flashes (10 seconds) later the shutter will capture the image.

Connecting the Camera to a PC

Place the CD title in your CD drive. If the Autorun program is installed the installation menu will appear. Follow the simple menu driven instructions to load the software. If the Autorun is not enabled or the installation menu does not appear.

1. Open the Windows Explorer or File Manager program.
2. Click on the CD drive
3. Select install driver from the installation menu
4. Select install applications from the installation menu
5. Connect camera to the computer with the connector cable
6. Startup the (just loaded) software application and you can begin editing your images.

Sound Indication

Condition	Sound	Condition	Sound
Camera ready to snapshot	Two short high tone	Snapshot success	One long high tone
Snapshot failure	Three short low tone	Snapshot 20 pictures	One long high tone and four short low tone
Memory full	LED bright	Memory full alarm sound when press snapshot button	Continuous short high tone
Camera stands for one minutes and its power doesn't turn off.	Two short high tone		