

MPP-3 Quick Start Guide:

Welcome to the MPP-3. Please review this guide in order to derive the maximum benefit and utility from your new purchase. By following the steps offered in this guide, you can be up and running easily.

First, what is the MPP-3?

- It is a digital parallel port camera with software drivers that enable it to work.
- It includes VideoLink™, a stand-alone software package that enables you to use your new camera to video conference over common phone lines to another person who is similarly equipped.
- It includes CU-SeeMe™, a stand-alone software package which enables you use your new camera to see, chat, and even talk to others over the Internet (or a Local Area Network).

What else is included?

There is much more on the CD-ROM.....

- A demo which talks about the MPP parallel port camera, in general terms.
- An extensive tutorial which shows you how to use VideoLink™ software.
- Free stuff! Check it out. There is a bunch of free software. There are nine titles including: MacroMedia's Shockwave™, Real Audio Player, 32-bit Apple® QuickTime™, and more.
- A CD store. This includes a multitude of software available for purchase from Smith-Micro. Load up your shopping basket, look for key discounts, and then call in your order.

What do I do now?

Step 1. Install the MPP camera (refer to hardware installation manual).

First, turn off your computer and **install the camera** (and the keyboard power cable) to your parallel port. There is a manual that tells you how. It is pretty simple. If you have a printer, you may wish to use a switch box. You may wish to consider eventually adding a second parallel port (LPT2) to your PC.

Step 2. After the camera is installed, install software from the CD-ROM.

Insert the CD-ROM. It's designed to run automatically. (Give it a couple of minutes.) If the CD doesn't run automatically, you can run it manually. Here's how: Press Start, Run, and type d:\autorun. Of course, if your CD-ROM drive is designated as a different drive letter, use that letter in place of the "d". An initial screen will appear. **Enter your name, organization, and the CD Key.** This is the CD key, not the CU-SeeMe™ serial number. (We will use that later). Click on "*Continue*". Enjoy the "helicopter logo" and then wait for the Main Screen to appear.

Step 3. In order for the MPP camera to operate, you must install the software drivers. (Required)

Install the MPP camera drivers. This is a must. To install the camera drivers, simply click on "*Video Drivers*". Select from the list of five languages and then follow the install screens. The installation will verify your camera and the LPT (parallel port) upon which it is installed. Note the information provided.

Step 4. Install VideoLink™ if you wish to video conference over common phone lines. (Optional)

Install VideoLink™ (if you desire to use VideoLink™) by simply clicking on "VideoLink™". Select the language you desire, and follow the screens. After VideoLink™ has been successfully installed, you have the option to either run VideoLink™ right now, or...return to the CD-ROM to install more software.

Step 5. Install CU-SeeMe™ if you wish to video conference over the Internet or LAN. (Optional)

Return to the CD-ROM Main Screen. Click on the “previous page” arrow (←) to navigate back to the Main Screen. Now, **click on Vivitar Digital Imaging.** This will take you to a screen which offers a VideoLink™ Demo, a VideoLink™ Tutorial, QuickTime™ for Windows®, and CU-SeeMe™. To install CU-SeeMe™, **click on the colorful CU-SeeMe™ icon.** Follow the instruction screens. When prompted, type in your CU-SeeMe™ serial number. After CU-SeeMe™ is installed, there will be a 202 page user manual installed to the (Windows® 95) path of c:\Program Files\CU-SeeMe\manuals\Cuseeme.pdf. This is an Acrobat® file. You must use Acrobat® reader to view or print it. Acrobat® Reader 3.0 is included on the MPP-3 CD. Using Windows® Explorer you can find Acrobat® reader at d:\cdbuild\programs\cuseeme\cuseess\adobe\disk1\setup.exe. This manual contains everything you need to know about CU-SeeMe™.

Step 6. Install QuickTime™. (Optional, but required if you wish to run the DEMO and Tutorials.)

If you do not have **QuickTime™**, go ahead and install it from the CD. QuickTime™ is a multimedia application set that allows you to view images and video movies on your PC. QuickTime™ for Windows® is a product of Apple® Computers and it is designed to work on a PC. You will need QuickTime™ 2.01 in order to view the VideoLink™ Demo and the VideoLink™ Tutorial. The MPP-3 CD actually has two versions of QuickTime™: a 16-bit version (for Windows® 3.1x users) and a 32-bit version for Windows® 95 users. You may install the 16-bit QuickTime™ version 2.01 by clicking on the colorful icon which says “QuickTime™ Installation”. You may also install the 32-bit version (version 2.1.2), go back to the main CD screen, click on “Free Stuff”, and then click on “QuickTime™”. If you already have QuickTime™ installed on your computer, the installer will detect the previous installation. Follow the screen instructions and feel free to “Skip” the installation of files that are older than the ones you may already have installed. The final result of the QuickTime™ installation will be Movie Player and Picture Viewer. It is okay to install both the 16 and 32 bit versions; they can co-exist just fine. Further updates to QuickTime™ are available from Apple® at www.apple.com.

Step 7. Run the MPP Demo and Tutorial. (Optional)

These two multimedia presentations are informative, video-based (using QuickTime™) dissertations which discuss the MPP and VideoLink™. They run from the CD. Simply **click on DEMO or Tutorial.** Important Hint: to stop the DEMO and return to the CD main screen, hit the escape (ESC) key. You could copy these presentations to your hard drive but that would consume considerable space, so I suggest you run them from the CD. These pieces are optional, but we highly recommend them (especially the tutorial) because: 1) they are highly informative, and 2) we worked very hard to produce them!!!! ☺

Step 8. Check out the rest of the CD-ROM. (Optional)

From the main screen, click on the various icons to go shopping (Smith micro-rama, Education & Entertainment, and Productivity). Look for discounts as you order multiple software titles from the Smith Micro fulfillment center. Next, click on “Free Stuff” to check out all the free and demo software that is also included. Much of it is very good, and very useful. Please note that any of the purchased software and free software provided here are the products of various third party vendors and developers. Please consult the appropriate vendor if you have any questions or need support.

We truly hope you enjoy your new MPP-3,